

# Goyen Solenoid Valve-Kits

## PILOT SOLENOID VALVES



RCA5D2



RCA-3DM (QR Coil)



M-735



RCA3DS (QD Coil)



RCA3PV (SB4 Coil)



K-0380

Solenoid Model No.	Description	Solenoid Valve Repair Kit	Coil Type	Protection Class
RCA3D2 (QT COIL)	1/8" npt PILOT SOLENOID VALVE (Integral or Remote), SCREW SPADES	<u>K0380 / (M1131B)</u>	QT (SCREW SPADE)	-
RCA3D2 (QR COIL)	1/8" npt PILOT SOLENOID VALVE (Integral or Remote), DIN SOCKET	<u>K0380 / (M1131B)</u>	QR (DIN SOCKET)	IP64
RCA3D2 (QD COIL)	1/8" npt PILOT SOLENOID VALVE (Integral or Remote), DUSTPROOF	<u>K0380 / (M1131B)</u>	QD (CONDUIT)	IP31
RCA3D2 (QF COIL)	1/8" npt PILOT SOLENOID VALVE (Integral or Remote), FLYING LEADS	<u>K0380 / (M1131B)</u>	QF (FLYING LEADS)	IP64
RCA5D2 (B2 COIL)	1/4" npt PILOT SOLENOID VALVE (Integral or Remote), SCREW SPADES	<u>K0580 / (M1141B)</u>	B2 COIL	-
RCA3DS-xxx	MILLENNIUM-SERIES PILOT SOLENOID VALVE	<u>K0380 / (M1131B)</u>	QR (DIN SOCKET)	IP64
RCA3DM-xxx	4-SERIES PILOT SOLENOID VALVE (CSA-listed), QR-COIL	<u>K0380</u>	QR (DIN SOCKET)	IP64
RCA3DM-xxx	4-SERIES PILOT SOLENOID VALVE (CSA-listed), QD-COIL	<u>K0380</u>	QD (CONDUIT)	IP31
RCA3PV-xxx	4-SERIES PILOT SOLENOID VALVE (CE-listed), COIL WITH DIN PLUG	N/A	SB4 K0203-K0206	IP65

\* Note: "xxx" Denotes P/N suffix required to specify coil voltage \*

